

Model JYB-DW

Tiny Differential Pressure Transmitter

DESCRIPTION

Model JYB-DW is a cost efficient and tiny differential pressure transmitter for atmosphere in dry rugged environments. The transmitter uses our proprietary current output with wide temperature compensation. This design references the primary pressure sensing diaphragm to the atmosphere, and provides a stable zero regardless of the transducer environment.



FEATURES

- 0.04 % FS/°F temperature effect
- 1.0 % accuracy
- 0.07 psig (500Pa) to 0.7psig (5000Pa) range
- 4 to 20 mA, 0 to 5VDC or RS-485/232
- Enhanced temperature stability
- CE Certification

PRESSURE MEASUREMENT

TRESSURE WEASUREMENT							
Supply Voltage	12 to 30VDC						
Operating Range	Any zero based full scale from 0.07psi(500 Pa) to 0.7psi (5000 bar)						
Over Pressure	Two times for the full scale						
Output Signal	Current two-wire 4mA to 20mA (Load $< 500\Omega$); Voltage 0 to 5VDC						
Pressure Media	Dry gas without cankering						
PERFORMANCE SPECIFICATIONS							
Accuracy	±1.0% (25°C)						
Response	<100ms						
Long Term Stability	<0.2% FS per year						
Temperature Range	-10 to 60°C						
Temperature	Max 1.0% FS typical over 0 to 60°C						
Effects	Max 1.5% FS typical over -20 to 85℃						
PHYSICAL CO	NNECTION						
Pressure Connection	M8x1.0 screw-in adaptor						
Electrical Connection	Cable Line						


ORDERING CODES

KING CODES								
w								
	I1	Current two-wire 4 ma to 20 ma						
	V1	Voltage 0 to 5VDC						
	W1	RS-232						
	W2	RS-232						
		M1	M8	M8x1.0 screw-in adaptor				
			S1	0-0.07psi				
		S2	0-0.1psi					
S 3			S3	0-0.2psi				
S4			S4	0-0.5psi				
			S5	0-0.7psi				
				D1	LED display			
				D2	LCD display			


ELECTRICAL CONNECTION

Code	1(Red)	2(Green)	3(Blue)	4(Black)
I1	+Supply	NC	Shell	-Supply
V1	+Supply	Out	Shell	GND
W1	+Supply	485+(A)	485-(B)	GND
W2	+Supply	232Rx	232Tx	GND


• Current two-wire 4ma to 20mA



• Voltage three-wire 0v to 5v



MOUNTING DIMENSION



NOTES

- 1 Because the sensor belongs to the precision component, in order to prevent damages of the product, don't disassemble voluntarily and touch a film slice, please.
- 2• When make a survey of high-pressure, must install buffer equipment in the exit of the connection between the sensor and the medium, which can avoid the momentary pulse high-pressure and the damages of sensors.
- 3• Accuracies stated are expected for best fit straight line for all errors including linearity, hysteresis & non-repeatability thru zero.
- 4• When install the pressure transmitter, must use the spanner from the bottom of the nut to screw tightly, avoid directly turning on the upside.
- 5• In order to production's airproof, our advice is use Φ 6- Φ 8 wiring from the side of terminal.
- 6. This production only measures non-corrosive dry gas.